

ЗИМНЯЯ АКЦИЯ

БУДЬ ГОТОВ К НОВОМУ СЕЗОНУ




ОРИГИНАЛЬНЫЕ ЗАПЧАСТИ И НАБОРЫ ЗАПЧАСТЕЙ BOMAG

ЦЕНОВОЕ ПРЕДЛОЖЕНИЕ В СИЛЕ

С 01/12/2020 ПО 31/03/2021

ЗАКАЖИ СЕЙЧАС И ПОЛУЧИ
МАКСИМАЛЬНУЮ ВЫГОДУ





770 837 45

SW1 – 1000H SERVICE KIT

MACHINE	SERIAL NUMBER	P/N KIT
BF 200	821 890 02 1001 - 821 890 02 9999	770 890 07
	821 890 03 1001 - 821 890 03 9999	
	821 890 07 1001 - 821 890 07 9999	
	821 890 08 1001 - 821 890 08 9999	
	821 890 09 1001 - 821 890 09 9999	
BF 223	821 837 37 1001 - 821 837 37 9999	770 890 01
	821 890 01 1001 - 821 890 01 0013	770 899 01
	821 890 01 1014 - 821 890 01 9999	
BF 300	821 837 56 1001 - 821 837 56 9999	770 837 56
	821 837 57 1001 - 821 837 57 9999	
	821 891 04 1001 - 821 891 04 9999	
	821 891 06 1001 - 821 891 06 9999	
	821 891 08 1001 - 821 891 08 9999	
	821 891 10 1001 - 821 891 10 9999	
	821 891 12 1001 - 821 891 12 9999	



MACHINE	SERIAL NUMBER	P/N KIT
BF 300	821 837 68 1001 - 821 837 68 9999	770 837 57
	821 837 82 1001 - 821 837 82 9999	
	821 891 01 1001 - 821 891 01 9999	
	821 891 02 1001 - 821 891 02 9999	
	821 891 03 1001 - 821 891 03 9999	
	821 891 05 1001 - 821 891 05 9999	
	821 891 07 1001 - 821 891 07 9999	
	821 891 09 1001 - 821 891 09 9999	
	821 891 11 1001 - 821 891 11 9999	
	821 891 21 1001 - 821 891 21 9999	
	821 891 20 1001 - 821 891 20 1007	770 891 17
	821 891 20 1008 - 821 891 20 9999	770 891 18
BF 300-2	821 891 17 1001 - 821 891 17 0033	770 891 17
	821 891 18 1001 - 821 891 18 0051	770 891 18
	821 891 17 1034 - 821 891 17 9999	
	821 891 18 1052 - 821 891 18 9999	
BF 331	821 837 21 0001 - 821 837 21 9999	770 837 00
BF 600	821 837 45 1001 - 821 837 45 9999	770 837 45
	821 837 46 1001 - 821 837 46 9999	
	821 837 47 1001 - 821 837 47 9999	
	821 837 48 1001 - 821 837 48 9999	
	821 837 49 1001 - 821 837 49 9999	
	821 837 501 001 - 821 837 50 9999	
	821 837 52 1001 - 821 837 52 9999	
	821 837 60 1001 - 821 837 60 9999	
	821 837 61 1001 - 821 837 61 9999	
	821 837 83 1001 - 821 837 83 9999	
	821 837 84 1001 - 821 837 84 9999	
	821 837 85 1001 - 821 837 85 9999	
	821 837 86 1001 - 821 837 86 9999	
	821 837 87 1001 - 821 837 87 9999	
	821 837 89 1001 - 821 837 89 9999	
	821 837 90 1001 - 821 837 90 9999	



MACHINE	SERIAL NUMBER	P/N KIT
BF 600-2	821 892 09 1001 - 821 892 09 9999	770 892 09
	821 892 10 1001 - 821 892 10 9999	
	821 892 13 1001 - 821 892 13 9999	
	821 892 14 1001 - 821 892 14 9999	770 892 10
	821 892 08 1001 - 821 892 08 9999	
	821 892 16 1001 - 821 892 16 9999	770 837 18
	821 832 17 1001 - 821 832 17 9999	
	821 892 201 001 - 821 892 20 9999	
	821 892 21 1001 - 821 892 21 9999	770 892 01
	821 892 02 1001 - 821 892 02 9999	
BF 691	821 892 04 1001 - 821 892 04 9999	
	821 837 63 1001 - 821 837 63 9999	770 837 38
	821 837 75 1002 - 821 837 75 9999 (*)	
	821 837 80 0007 - 821 837 80 9999	770 837 41
BF 700-2	821 837 73 1001 - 821 837 73 9999	
	821 892 05 1001 - 821 892 05 9999	770 892 01
	821 892 06 1001 - 821 892 06 9999	
	821 892 11 1001 - 821 892 11 9999	770 892 09
	821 892 12 1001 - 821 892 12 9999	
	821 892 18 1001 - 821 892 18 9999	770 837 18
BF 800	821 892 19 1001 - 821 892 19 9999	
	821 837 17 1001 - 821 837 17 9999	770 837 17
	821 837 19 1001 - 821 837 19 9999	
	821 893 27 1001 - 821 893 27 9999	
	821 837 65 1001 - 821 837 65 9999	
	821 837 66 1001 - 821 837 66 9999	
	821 837 70 1001 - 821 837 70 9999	
	821 837 71 1001 - 821 837 71 9999	770 837 18
	821 837 17 1061 - 821 837 17 9999	
	821 837 19 1154 - 821 837 19 9999	
	821 837 65 0013 - 821 837 65 9999	
	861 884 09 1001 - 861 884 09 9999	
	861 893 11 1001 - 861 893 11 9999	

SERVICE KITS - SW1 & SW6.

10% СКИДКА

MACHINE	SERIAL NUMBER	P/N KIT
BF 800	821 893 01 1001 - 821 893 01 9999	770 893 07
	821 893 02 1001 - 821 893 02 9999	
	821 893 05 1001 - 821 893 05 9999	
	821 893 06 1001 - 821 893 06 9999	
	821 893 20 1001 - 821 893 20 9999	
	821 893 28 1001 - 821 893 28 9999	
BF 800-2	821 893 29 1001 - 821 893 29 9999	770 893 15
	821 893 15 1001 - 821 893 15 9999	
BF 900	821 893 08 1001 - 821 893 08 9999	770 893 07
	821 893 09 1001 - 821 893 09 9999	
	821 893 31 1001 - 821 893 31 9999	
	821 893 12 1001 - 821 893 12 9999	
	821 893 13 1001 - 821 893 13 9999	
	821 893 24 1001 - 821 893 24 9999	

* Проверьте серийный номер



SW6 – 500H OIL SERVICE KIT

MACHINE	SERIAL NUMBER	P/N KIT
BF 200	821 890 02 1001 - 821 890 02 9999	775 890 07
	821 890 03 1001 - 821 890 03 9999	
	821 890 07 1001 - 821 890 07 9999	
	821 890 08 1001 - 821 890 08 9999	
	821 890 09 1001 - 821 890 09 9999	

SERVICE KITS - SW6.

10% СКИДКА



MACHINE	SERIAL NUMBER	P/N KIT
BF 223	821 837 37 1001 - 821 837 37 9999	775 837 37
	821 890 01 1001 - 821 890 01 0013	
	821 890 01 1014 - 821 890 01 9999	
BF 300	821 837 56 1001 - 821 837 56 9999	775 837 56
	821 837 57 1001 - 821 837 57 9999	
	821 891 04 1001 - 821 891 04 9999	
	821 891 06 1001 - 821 891 06 9999	
	821 891 08 1001 - 821 891 08 9999	
	821 891 10 1001 - 821 891 10 9999	
	821 891 12 1001 - 821 891 12 9999	
	821 837 68 1001 - 821 837 68 9999	
	821 837 82 1001 - 821 837 82 9999	
	821 891 01 1001 - 821 891 01 9999	
	821 891 02 1001 - 821 891 02 9999	
	821 891 03 1001 - 821 891 03 9999	
BF 300	821 891 05 1001 - 821 891 05 9999	775 837 56
	821 891 07 1001 - 821 891 07 9999	
	821 891 09 1001 - 821 891 09 9999	
	821 891 11 1001 - 821 891 11 9999	
	821 891 21 1001 - 821 891 21 9999	
	821 891 20 1001 - 821 891 20 1007	775 891 17
	821 891 20 1008 - 821 891 20 9999	775 891 18
BF 300-2	821 891 17 1001 - 821 891 17 0033	775 891 17
	821 891 18 1001 - 821 891 18 0051	
	821 891 17 1034 - 821 891 17 9999	775 891 18
	821 891 18 1052 - 821 891 18 9999	
BF 331	821 837 21 0001 - 821 837 21 9999	775 837 00

MACHINE	SERIAL NUMBER	P/N KIT
BF 600	821 837 45 1001 - 821 837 45 9999	775 837 46
	821 837 46 1001 - 821 837 46 9999	
	821 837 47 1001 - 821 837 47 9999	
	821 837 48 1001 - 821 837 48 999	
	821 837 49 1001 - 821 837 49 9999	
	821 837 501 001 - 821 837 50 9999	
	821 837 52 1001 - 821 837 52 9999	
	821 837 60 1001 - 821 837 60 9999	
	821 837 61 1001 - 821 837 61 9999	
	821 837 83 1001 - 821 837 83 9999	
	821 837 84 1001 - 821 837 84 999	
	821 837 85 1001 - 821 837 85 999	
	821 837 86 1001 - 821 837 86 9999	
	821 837 87 1001 - 821 837 87 9999	
	821 837 89 1001 - 821 837 89 9999	
	821 837 90 1001 - 821 837 90 9999	
BF 600-2	821 892 09 1001 - 821 892 09 9999	775 837 46
	821 892 10 1001 - 821 892 10 9999	
	821 892 13 1001 - 821 892 13 9999	
	821 892 14 1001 - 821 892 14 9999	775 837 46
	821 892 08 1001 - 821 892 08 9999	
	821 892 16 1001 - 821 892 16 9999	775 837 17
	821 832 17 1001 - 821 832 17 9999	
BF 600-2	821 892 201 001 - 821 892 20 9999	775 837 17
	821 892 21 1001 - 821 892 21 9999	775 892 02
	821 892 02 1001 - 821 892 02 9999	
	821 892 04 1001 - 821 892 04 9999	
BF 691	821 837 63 1001 - 821 837 63 9999	775 837 38
	821 837 75 1002 - 821 837 75 9999 (*)	
	821 837 80 0007 - 821 837 80 9999	775 837 17
	821 837 73 1001 - 821 837 73 9999	





MACHINE	SERIAL NUMBER	P/N KIT
BF 700-2	821 892 05 1001 - 821 892 05 9999	775 892 02
	821 892 06 1001 - 821 892 06 9999	
	821 892 11 1001 - 821 892 11 9999	775 837 46
	821 892 12 1001 - 821 892 12 9999	
	821 892 18 1001 - 821 892 18 9999	775 837 17
	821 892 19 1001 - 821 892 19 9999	
BF 800	821 837 17 1001 - 821 837 17 9999	775 837 17
	821 837 19 1001 - 821 837 19 9999	
	821 893 27 1001 - 821 893 27 9999	
	821 837 65 1001 - 821 837 65 9999	
	821 837 66 1001 - 821 837 66 9999	
	821 837 70 1001 - 821 837 70 9999	
	821 837 71 1001 - 821 837 71 9999	
	821 837 17 1061 - 821 837 17 9999	
	821 837 19 1154 - 821 837 19 9999	
	821 837 65 0013 - 821 837 65 9999	
	861 884 09 1001 - 861 884 09 9999	
	861 893 11 1001 - 861 893 11 9999	
	821 893 01 1001 - 821 893 01 9999	
	821 893 02 1001 - 821 893 02 9999	
	821 893 05 1001 - 821 893 05 9999	
	821 893 06 1001 - 821 893 06 9999	
	821 893 20 1001 - 821 893 20 9999	
	821 893 28 1001 - 821 893 28 9999	
	821 893 29 1001 - 821 893 29 9999	
BF 800-2	821 893 15 1001 - 821 893 15 9999	775 893 15
BF 900	821 893 08 1001 - 821 893 08 9999	775 837 17
	821 893 09 1001 - 821 893 09 9999	
	821 893 31 1001 - 821 893 31 9999	
	821 893 12 1001 - 821 893 12 9999	
	821 893 13 1001 - 821 893 13 9999	
	821 893 24 1001 - 821 893 24 9999	


ОРИГИНАЛЬНЫЕ ЗАПЧАСТИ И НАБОРЫ ЗАПЧАСТЕЙ ДЛЯ

УКЛАДЧИКОВ ВОМАГ

WEAR PLATES, KIT.

10 % СКИДКА

10%
СКИДКА



837 015 94

MACHINE	P/N KIT
BF 200	890 010 37
BF 222	837 017 23
BF 223	837 017 23
BF 300	891 010 27
BF 331	837 017 25
BF 600	837 017 29
BF 600-2	837 017 76
BF 700-2	837 017 76
BF 691	837 017 31
BF 800	837 015 94
BF 900	837 015 94

ОРИГИНАЛЬНЫЕ ЗАПЧАСТИ И НАБОРЫ ЗАПЧАСТЕЙ
ДЛЯ УКЛАДЧИКОВ VOMAG
CENTRAL AND LATERAL GUARD HOPPER.

10 % СКИДКА


10%
СКИДКА



837 017 28

MACHINE	P/N KIT
BF 200	890 010 36
BF 222	837 017 24
BF 223	837 017 24
BF 300	837 017 28
BF 300-2	891 010 13
BF 600	837 017 30
BF 600-2	837 017 77
BF 691	837 017 32
BF 700-2	837 017 78
BF 800	837 015 95
BF 800-2	893 010 90
BF 900	837 015 95

SLAT CONVEYOR CHAIN, KIT.



MACHINE	P/N KIT
BF 200	890 010 29
BF 222	890 010 06
BF 223	890 010 06
BF 300	837 017 02
BF 300-2	891 010 10
BF 331	837 017 01
BF 600	837 017 03
BF 600-2	837 017 73
BF 691	837 017 04
BF 700-2	837 017 74
BF 800	837 017 05
BF 800-2	837 017 05
BF 900	837 017 05

**10%
СКИДКА**

837 012 06

MACHINE	P/N KIT
BF 200	890 010 30
BF 222	837 012 06
BF 223	837 012 06
BF 300	837 013 90
BF 300-2	891 010 33
BF 331	837 012 07
BF 600	837 012 08
BF 600-2	837 017 75
BF 700-2	837 017 75
BF 800-2	837 017 75
BF 691	837 012 09
BF 800	837 015 98
BF 900	837 015 98

ОРИГИНАЛЬНЫЕ ЗАПЧАСТИ И НАБОРЫ ЗАПЧАСТЕЙ ДЛЯ
УКЛАДЧИКОВ ВОМАГ.

AUGER SEGMENT, KITS.

10 % СКИДКА

10%
СКИДКА



837 017 08

MACHINE	P/N - AUGER SEGMENT LEFT	P/N - AUGER SEGMENT RIGHT
BF 222	837 017 07	837 017 08
BF 223	837 017 07	837 017 08
BF 300	837 017 07	837 017 08
BF 300-2	837 017 07	837 017 08
BF 600	837 017 10	837 017 09
BF 600-2	837 017 10	837 017 09
BF 691	837 017 12	837 017 11
BF 700-2	837 017 12	837 017 11
BF 800	837 017 12	837 017 11
BF 800-2	837 017 12	837 017 11
BF 900	837 017 85	837 017 86

ОРИГИНАЛЬНЫЕ ЗАПЧАСТИ И НАБОРЫ ЗАПЧАСТЕЙ ДЛЯ
УКЛАДЧИКОВ ВОМАГ

10 % СКИДКА

AUGER SEGMENTS BASIC SCREED, KITS.

10%
СКИДКА



837 013 89

MACHINE	P/N KIT
BF 200	890 010 12
BF 222	837 011 84
BF 223	837 011 84
BF 300	837 013 89
BF 300-2	837 013 89
BF 331	837 013 89
BF 600	837 017 13
BF 600-2	837 017 79
BF 691	837 017 33
BF 700-2	837 017 80
BF 800	837 017 34
BF 800-2	837 017 34
BF 900	837 017 87

10%
СКИДКА



837 015 61

MACHINE	P/N KIT
BF 200	890 010 43
BF 222	837 015 61
BF 223	837 015 61
BF 300	837 015 62
BF 300-2	837 015 62
BF 331	837 015 62
BF 600-2	837 017 81
BF 700-2	837 017 81
BF 900	837 017 81
BF 691	837 017 06
BF 800	837 016 54
BF 800-2	837 016 54

ОРИГИНАЛЬНЫЕ ЗАПЧАСТИ И НАБОРЫ ЗАПЧАСТЕЙ ДЛЯ

УКЛАДЧИКОВ BOMAG

SCREED PLATES, KIT.

10 % СКИДКА

10%
СКИДКА



837 017 35

MACHINE	SCREED	SERIAL NUMBER	P/N KIT
BF 200	TV	—	890 010 38
BF 222	—	—	837 012 78
BF 223	—	—	837 012 82
BF 300	S340 V	—	837 017 40
	S340 TV	—	837 017 41
	S340-2V	—	894 010 32
	S340-2TV	—	894 010 31
BF 300-2	S340-2 V	—	894 010 32
	S340-2 TV	—	894 010 31
BF 331	—	—	837 017 35
BF 600	HCE	—	837 017 45
	HCG	—	837 017 37
	HSE	—	837 017 42
	HSG	—	837 017 38

MACHINE	SCREED	SERIAL NUMBER	P/N KIT
BF 600-2	S500	821 892 02 1001 - 821 892 02 9999	837 017 43
		821 892 04 1001 - 821 892 04 9999	
		821 892 08 1001 - 821 892 08 9999	
	S600	821 892 09 1001 - 821 892 09 9999	837 017 44
	S500	821 892 10 1001 - 821 892 10 9999	837 017 43
	S600	821 892 13 1001 - 821 892 13 9999	895 010 73
		821 892 16 1001 - 821 892 16 9999	
	S500	821 892 17 1001 - 821 892 17 9999	895 010 74
	S600	821 892 20 1001 - 821 892 20 9999	895 010 73
	S500	821 892 21 1001 - 821 892 21 9999	895 010 74
BF 691	—	—	837 017 42
BF 700-2	S600	821 892 05 1001 - 821 892 05 1009	837 017 44
		821 892 05 1010 - 821 892 05 9999	895 010 73
	S500	821 892 06 1001 - 821 892 06 1024	837 017 43
		821 892 06 1025 - 821 892 06 9999	895 010 74
	S600	821 892 11 1001 - 821 892 11 9999	895 010 73
	S500	821 892 12 1001 - 821 892 12 9999	895 010 74
	S600	821 892 18 1001 - 821 892 18 9999	895 010 73
	S500	821 892 19 1001 - 821 892 19 9999	895 010 74
BF 800	S500	821 837 17 1001 - 821 837 17 1069	837 017 43
		821 837 17 1070 - 821 837 17 9999	895 010 74
	S600	821 837 19 0001 - 821 837 19 0189	837 017 44
		821 837 19 0190 - 821 837 19 9999	895 010 73
	S500	821 837 65 0001 - 821 837 65 0012	837 017 43
		821 837 65 0013 - 821 837 65 9999	895 010 74
	S600	821 837 66 1001 - 821 837 66 9999	837 017 44
	S500	821 837 70 1001 - 821 837 70 9999	837 017 43
		821 837 71 1001 - 821 837 71 9999	
	S600	821 837 93 1001 - 821 837 93 9999	837 017 44
		821 837 96 1001 - 821 837 96 1043	
	S500	821 893 01 1001 - 821 893 01 9999	837 017 43
	S600	821 893 02 1001 - 821 893 02 9999	837 017 44





MACHINE	SCREED	SERIAL NUMBER	P/N KIT
BF 800	S500	821 893 05 1001 - 821 893 05 9999	837 017 43
	S600	821 893 06 1001 - 821 893 06 9999	837 017 44
	S500	821 893 19 1001 - 821 893 19 9999	895 01 074
	S600	821 893 20 1001 - 821 893 20 9999	895 01 073
		821 893 22 1001 - 821 893 22 9999	
	S500	821 893 27 1001 - 821 893 27 9999	895 010 74
		821 893 28 1001 - 821 893 28 9999	
	S600	821 893 29 1001 - 821 893 29 9999	895 010 73
		861 893 50 1001 - 861 893 50 9999	
	S500	861 893 60 1001 - 861 893 60 9999	895 010 74
BF 800-2	S300	861 884 09 1001 - 861 884 09 9999	
	S600	861 893 11 1001 - 861 893 11 9999	895 010 73
	S500	—	895 010 74
	S500	821 893 08 1001 - 821 893 08 9999	837 017 43
		821 893 12 1001 - 821 893 12 1001	
		821 893 12 1002 - 821 893 12 9999	895 010 74
	S600	821 893 24 1001 - 821 893 24 1001	895 010 73
		821 893 09 1001 - 821 893 09 9999	837 017 44
		821 893 13 1001 - 821 893 13 1002	
		821 893 13 1003 - 821 893 13 9999	895 010 73
		821 893 31 1001 - 821 893 31 9999	

**10%
СКИДКА**

837 017 50

MACHINE	SCREED	SERIAL NUMBER	P/N KIT
BF 200	—	—	890 010 32 / 890 010 49 *
BF 300	S340 TV	—	837 017 50
BF 300-2	S340-2 TV	—	837 017 70
BF 600	HCE	—	837 012 89
	HCG	—	837 017 47
	HSE	—	837 017 51
	HSG	—	837 017 48
BF 600-2	S500	821 892 02 1001 - 821 892 02 9999	837 017 52
		821 892 04 1001 - 821 892 04 9999	
		821 892 08 1001 - 821 892 08 9999	
	S600	821 892 09 1001 - 821 892 09 9999	837 017 53
	S500	821 892 10 1001 - 821 892 10 9999	
	S600	821 892 13 1001 - 821 892 13 9999	895 010 71
		821 892 16 1001 - 821 892 16 9999	
	S500	821 892 17 1001 - 821 892 17 9999	895 010 69
	S600	821 892 20 1001 - 821 892 20 9999	895 010 71
	S500	821 892 21 1001 - 821 892 21 9999	895 010 69
BF 691	HB	—	837 017 49
	HSE	—	837 017 51
BF 700-2	S500	—	837 017 52
BF 900	S600	—	837 017 53



MACHINE	SCREED	SERIAL NUMBER	P/N KIT
BF 800	S500	821 837 17 1001 - 821 837 17 1069	837 017 52
		821 837 17 1070 - 821 837 17 9999	895 010 69
	S600	821 837 19 0001 - 821 837 19 0189	837 017 53
		821 837 19 0190 - 821 837 19 9999	895 010 71
	S500	821 837 65 0001 - 821 837 65 0012	837 017 52
		821 837 65 0013 - 821 837 65 9999	895 010 69
	S600	821 837 66 1001 - 821 837 66 9999	895 010 71
	S500	821 837 70 1001 - 821 837 70 9999	837 017 52
		821 837 71 1001 - 821 837 71 9999	
	S600	821 837 93 1001 - 821 837 93 9999	837 017 53
		821 837 96 1001 - 821 837 96 9999	
	S500	821 893 01 1001 - 821 893 01 9999	837 017 52
	S600	821 893 02 1001 - 821 893 02 9999	837 017 53
	S500	821 893 05 1001 - 821 893 05 9999	837 017 52
	S600	821 893 06 1001 - 821 893 06 9999	837 017 53
	S500	821 893 19 1001 - 821 893 19 9999	895 010 69
	S600	821 893 20 1001 - 821 893 20 9999	895 010 71
		821 893 22 1001 - 821 893 22 9999	
	S500	821 893 27 1001 - 821 893 27 9999	895 010 69
		821 893 28 1001 - 821 893 28 9999	
	S600	821 893 29 1001 - 821 893 29 9999	895 010 71
		861 893 50 1001 - 861 893 50 9999	
	S500	861 893 60 1001 - 861 893 60 9999	895 010 69
	S300	861 884 09 1001 - 861 884 09 9999	
	S600	861 893 11 1001 - 861 893 11 9999	895 010 71

*Please ask us for more information

ОРИГИНАЛЬНЫЕ ЗАПЧАСТИ И НАБОРЫ ЗАПЧАСТЕЙ ДЛЯ
УКЛАДЧИКОВ ВОМАГ
TAMPER BEARINGS, KITS.

10 % СКИДКА

10%
СКИДКА



837 017 93



MACHINE	SCREED	REQUIRED QUANTITY PER MACHINE	P/N KIT
BF 200	—	—	890 01031
BF 300	S340 TV	8	837 017 94
BF 300-2	S340-2 TV	8	837 017 95
BF 600	HCE/HCG	8	837 017 97
	HSE/HSG	8	837 017 96
BF 600-2	—	8	837 017 93
BF 691	—	8	837 017 96
BF 700-2	—	8	837 017 93
BF 800	—	8	837 017 93
BF 800-2	—	8	837 017 93
BF 900	—	8	837 017 93

10%
СКИДКА

837 017 93

MACHINE	SCREED	P/N KIT	DESCRIPTION
BF 200	—	890 010 47	Kit includes 4 heating rods
BF 223	—	837 014 02	Kit includes 8 heating rods
BF 300	—	837 016 66	Kit includes 4 heating rods
BF 300-2	—	837 016 66	Kit includes 4 heating rods
BF 600	HC	837 014 06	Kit includes 12 heating rods
	HS	837 014 05	Kit includes 16 heating rods
BF 691	HC	837 014 06	Kit includes 12 heating rods
	HS	837 014 05	Kit includes 16 heating rods
BF 600-2	S500	837 016 48	Kit includes 4 heating rods
	S600	837 016 50	
BF 700-2	S500	837 016 48	Kit includes 4 heating rods
	S600	837 016 50	
BF 800	S500	837 016 48	Kit includes 4 heating rods
	S600	837 016 50	
BF 800-2	S500	837 016 48	Kit includes 4 heating rods
	S600	837 016 50	
BF 900	S500	837 016 48	Kit includes 4 heating rods
	S600	837 016 50	

TRACK ROLLERS, KITS.



MACHINE	OTHER SERIAL NUMBERS	REQUIRED QUANTITY PER TRACK	P/N KIT
BF 200		6	890 010 40
BF 222	—	7	837 014 09
BF 223	—	7	837 014 09
BF 300	C-Machines	7	837 014 50 (front)
		1	837 014 51 (rear)
BF 300-2	C-Machines	7	891 010 16 (front)
		1	891 010 17 (rear)
BF 600	821 837 45 0001 - 821 837 45 9999	8	837 014 11
	821 837 46 0001 - 821 837 46 9999		
	821 837 47 0001 - 821 837 47 9999		
	821 837 48 0001 - 821 837 48 9999		
	821 837 53 1001 - 821 837 53 9999	8	837 017 98
	821 837 61 1001 - 821 837 61 9999		
	821 837 85 1001 - 821 837 85 9999		
	821 837 86 1001 - 821 837 86 9999		
	821 837 90 1002 - 821 837 90 9999		
	821 837 89 1001 - 821 837 89 9999		
BF 600-2	—	3	837 017 83 (rear)
		6	837 017 82 (front)
BF 700-2	—	3	837 017 83 (rear)
		6	837 017 82 (front)

TRACK ROLLERS, KITS.

MACHINE	OTHER SERIAL NUMBERS	REQUIRED QUANTITY PER TRACK	P/N KIT
BF 691	—	8	837 014 11 (front)
	—	2	837 014 12 (rear)
BF 800	821 837 17 1001 - 821 837 17 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 837 19 0001 - 821 837 19 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 837 66 1001 - 821 837 66 9999	7	837 014 11 (front)
		3	837 014 12 (rear)
	821 837 66 1024 - 821 837 66 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 837 71 1001 - 821 837 71 9999	7	837 014 11 (front)
		3	837 014 12 (rear)
	821 837 93 1001 - 821 837 93 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 837 96 1001 - 821 837 96 9999	7	837 017 82 (front)
		3	058 700 60 rear
	821 893 01 1001 - 821 893 01 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 893 02 1001 - 821 893 01 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	861 893 11 1001 - 861 893 11 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 893 19 1001 - 821 893 19 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 893 20 1001 - 821 893 20 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 893 28 1001 - 821 893 28 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 893 29 1001 - 821 893 29 9999	7	837 017 82 (front)
		3	058 700 60 (rear)

TRACK ROLLERS, KITS.

MACHINE	OTHER SERIAL NUMBERS	REQUIRED QUANTITY PER TRACK	P/N KIT
BF 900	821 893 08 1001 - 821 893 08 9999	7	837 014 11 (front)
		3	837 014 12 (rear)
	821 893 09 1001 - 821 893 09 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 893 31 1001 - 821 893 31 1004	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 893 12 1002 - 821 893 12 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 893 13 1003 - 821 893 13 9999	7	837 017 82 (front)
		3	058 700 60 (rear)
	821 893 24 1001 - 821 893 24 1001	7	837 017 82 (front)
		3	058 700 60 (rear)



ОРИГИНАЛЬНЫЕ ЗАПЧАСТИ И НАБОРЫ ЗАПЧАСТЕЙ ДЛЯ
УКЛАДЧИКОВ ВОМАГ
TRACK PAD, KIT.

10 % СКИДКА

10%
СКИДКА



837 010 51


MACHINE	REQUIRED QUANTITY PER TRACK	P/N KIT
BF 222	39	837 010 49
BF 223	39	837 010 49
BF 300	41	837 013 93
BF 300-2	41	837 013 93
BF 600	44	837 010 51
BF 600-2	48	837 010 51
BF 700-2	48	837 010 51
BF 691	50	837 010 51
BF 800	53	837 010 51
BF 900	53	837 010 51
BF 800-2	53	837 015 65

ОРИГИНАЛЬНЫЕ ЗАПЧАСТИ И НАБОРЫ ЗАПЧАСТЕЙ ДЛЯ

УКЛАДЧИКОВ ВОМАГ

TRACK PADS, KIT.

10 % СКИДКА



MACHINE	P/N KIT
BF 200	890 010 41
BF 222	837 010 52
BF 223	837 010 52
BF 300	837 013 94
BF 300-2	837 013 94
BF 600	837 010 84
BF 600-2	837 018 02
BF 700-2	837 018 02
BF 691	837 011 65
BF 800	837 015 66
BF 900	837 015 66
BF 800-2	837 015 66

Head Office:

BOMAG

Hellerwald

56154 Boppard

GERMANY

Tel. +49 6742 100-0

Fax +49 6742 3090

info@bomag.com

BOMAG France S.A.S.

2, Avenue du Général de Gaulle

91170 Viry-Châtillon

FRANCE

Tel. +33 1 69578600

Fax +33 1 69962660

france@bomag.com

BOMAG (GREAT BRITAIN), LTD.

Sheldon Way

Larkfield, Aylesford

Kent ME20 6SE

GREAT BRITAIN

Tel. +44 1622 716611

Fax +44 1622 710233

gb@bomag.com

FAYAT BOMAG Polska Sp. z o.o.

Ul. Szyszkowa 52

02-285 Warszawa

POLAND

Tel. +48 22 482 04 00

Fax +48 22 482 04 01

poland@bomag.com

**BOMAG Maschinen-
handelsgesellschaft m.b.H.**

Klausenweg 654

2534 Alland

AUSTRIA

Tel. +43 2258 20202

Fax +43 2258 20202-20

austria@bomag.com

BOMAG Italia Srl.

Via Roma 50

48011 Alfonsine

ITALY

Tel. +39 0544 864235

Fax +39 0544 864367

italy@bomag.com

FAYAT BOMAG RUS 000

141400, RF, Moscow region

Khimki, Klayazma block, h. 1-g

RUSSIA

Tel. +7 (495) 287 92 90

Fax +7 (495) 287 92 91

russia@bomag.com

**ОФИЦИАЛЬНЫЙ ПРЕДСТАВИТЕЛЬ ЗАВОДА БОМАГ В
РЕСПУБЛИКЕ БЕЛАРУСЬ:**

ООО "БЕЛИНВЕСТТЕХСТРОЙ"

МИНСК, УЛ. МЕЛЕЖА, Д.1

+375 29 670 74 16

+375 29 198 84 14

WEB: WWW.BOMAG.BY

INFO@BOMAG.BY